



## **TRAILSLIDE INSTALLATION INSTRUCTIONS**

### **PART NUMBER: CG4XJK100**

1. Remove Drop In Rug and Cargo Lid from the rear cargo area of your Jeep JK, and set aside.
2. Remove the screws from the 4 existing D Ring Tie-Downs in the floor, 2 near the middle of the cargo area and 2 near the back of the seats with a T40 Size TORX tool.
3. Place the CG4XJK100 CargoGlide unit in the back of the Jeep locating the mounting holes in the frame over the D Ring holes that you removed the screws from.
  - a. Turn the latch release handle and extend the top deck a few inches to allow access to the mounting holes near the back of the seats.
  - b. Using the screws removed earlier, install the 2 screws through the CargoGlide units mounting holes back into the original locations the screws came from.
  - c. Extend the top deck all the way open and install the 2 screws into the middle mounting locations, one on each side of the CargoGlide frame.

**Check out [CargoGlide.com](http://CargoGlide.com) for the installation video for the TrailSlide.**

**Call CargoGlide at 877-525-9535 for support.**